SKY FLUX

SKY FLUX AUTO PARTS

KAMAZ Parts Catalogue

Complete spare parts catalogue for KAMAZ trucks in PDF: part numbers, names, applicability.

Edition 20.11.2026

116 items

Contents

PART NO.	NAME	PAGE
Engine		1
740-1005115	Flywheel assembly	1
740.30-1005115	Flywheel assembly	1
740.60-1005115	Flywheel assembly	1
7403-1000128	Complete cylinder liner and piston kit	1
7403.1000101	Cylinder liner and piston kit	2
7405-1005115	Flywheel assembly	2
7405.1004065	Piston cooling nozzle assembly	2
7405.1004066	Piston cooling nozzle valve assy	2
Cooling system		3
5320-1301010	Radiator assembly	3
54115-1301010	Radiator assembly	3
54115-1301010-10	Radiator assembly	3
Clutch		4
14.1601203	Clutch release fork	4
5320-1602510-10	Clutch master cylinder assembly	4
5320-1609510	Pneumohydraulic booster assembly	4
5320-1609510-30	Air-over-hydraulic booster	4
5320-1609510-40	Air-over-hydraulic booster	5
Gearbox		5
14.1701150	2nd and 3rd gear synchronizer assembly	5
15.1772100	Mechanism control reducing valve assy	5
15.1772132	Gear splitter control valve with cable assembly	6
152.1703620-20	Lever	6
362-1703521-20	Ball joint	6
362-1703620-20	Gear Shift Linkage Rod Assembly for KAMAZ 152 Gearbox	6
362-1703620-20СБ	Gear Shift Linkage Rod Assembly for KAMAZ 152 Gearbox	7

Propeller shafts 7

4310-2205025	Universal joint cross	7
53205-2205025	Spider assembly	7

Front axle 8

4310-2304062	Axle shaft	8
4310-2304064	Axle shaft	8
4310-2304065	Axle shaft	8
4310-2304066	Universal joint	8
4310-2304067	Disc	9
4310-2304090	Front wheel hub drive flange	9
4310-2304091	Axle shaft drive flange gasket	9
53228-2304064	Axle shaft	9
53228-2304065	Axle shaft	10

Rear axle 10

43118-2403069	Axle shaft	10
43118-2403070	Axle shaft	10
5320-2402017	Drive bevel gear	11
5320-2402020	Rear axle bevel gear set	11
5320-2402024	Rear axle drive shaft	11
5320-2402047	Bearing cup cover gasket	11
5320-2402060	Rear axle driven bevel gear	12
5320-2402110-10	Drive pinion	12
5320-2402120-10	Ring gear	12
5320-2402120-20	Driven spur gear	12
5320-2402120-30	Driven spur gear	13
5320-2402120-40	Driven spur gear	13
5320-2403055	Planet gear	13
5320-2403060	Cross pin	13
5320-2403070	Right short axle shaft	14
5320-2403071	Left long axle shaft	14

53205-2402036	Rear axle flange	14
53205-2402110-10	Drive spur gear	14
53205-2402175	Thrust washer	15
53205-2402188	Rear axle adjusting bushing	15
53205-2402189	Rear axle adjusting bushing	15
53205-2403050	Side gear	15
53205-2403070	Right axle shaft	16
53205-2403071	Left axle shaft	16
53229-2403016	Differential shell	16
53229-2403069	Axle shaft	16
53229-2403070	Axle shaft	17
53229-2403071	Left axle shaft	17
54115-2402051	Rear axle gearbox bearing cup cover	17
Intermediate axle		18
5320-2506037	Input shaft flange assembly	18
5320-2506058	Planet pinion washer	18
5320-2506130	Intermediate axle bevel gear	18
5320-2506131	Sleeve of interaxle differential middle axle drive gear	18
53205-2506054	Inter-axle differential planet pinion with bushing	19
53205-2506055-10	Inter-axle differential planet pinion without bushing	19
53205-2506060	Inter-axle differential spider	19
53205-2506063	Inter-axle differential planet pinion bushing	19
53205-2506081	Interaxle differential spider assembly with planet pinions without bushing (repair kit)	20
53205-2506081-20	Interaxle differential spider assembly (repair kit)	20
6520-2502036	Flange	20
Fifth wheel coupling		21
5320-2707212	Tow hook	21
Suspension		21
1630-2919010-20	Torque rod	21

5320-2918169	Balancer axle nut	21
5511-2918050	Balance shaft	22
65115-2918050	Balance shaft	22
65115Y-2918050	Balance shaft	22
6520-2918169	Balancer axle nut	22

Wheels and tyres 23

4310-3103076	Repair kit	23
4310-3103079	Repair kit	23
4310-3103081	Repair kit	23
4310-3103082	Repair kit	23
5320-3104076	Repair kit	24
5320-3104079	Repair kit	24
5320-3104081	Repair kit	24
5320-3104082	Repair kit	24
53205-3104000	Repair kit	25
53222-3104015	SZAP trailer hub	25
6520-3104000	Repair kit	25

Steering 26

4310-3407200	Power steering pump assembly	26
4310-3407200-01	Pump assembly	26
4310-3407200-01(-02)	Power steering pump	26
4310-3407200-02	Power steering pump	26
4310-3407200-20	Power steering pump	27
4310-3407200-21	Power steering pump	27
53205-3414010	Steering tie rod assembly	27
6520-3414010	Steering tie rod assembly	27

Brakes 28

100-3512010	Pressure regulator assembly	28
100-3512010-10	Pressure regulator assembly	28
100-3514008	Brake valve assembly	28

100-3514009	Dual-circuit brake valve repair kit	28
100-3514009-10	Dual-circuit brake valve repair kit	29
100-3515010	Single-circuit protection valve without reverse flow	29
100-3515210	Triple protection valve assy	29
100-3518010	Relay valve assy	29
100-3518010-10	Relay valve	30
100-3520010	Isolating valve assembly	30
100-3520010-10	Isolating valve assembly	30
100-3537010	Parking brake valve with manual control	30
53205-3501070	Brake drum	31
6520-3501070	Brake drum	31
Instruments		31
14.3830010	Oil pressure gauge	31
5320-3829010	Oil pressure gauge sender	31

Engine



Flywheel assembly
740-1005115



Flywheel assembly
740.30-1005115



Flywheel assembly
740.60-1005115



Complete cylinder liner and piston kit
7403-1000128



Cylinder liner and piston kit
7403.1000101



Flywheel assembly
7405-1005115



Piston cooling nozzle assembly
7405.1004065



Piston cooling nozzle valve assy
7405.1004066

Cooling system



Radiator assembly
5320-1301010



Radiator assembly
54115-1301010



Radiator assembly
54115-1301010-10

Clutch



Clutch release fork
14.1601203



Clutch master cylinder assembly
5320-1602510-10



Pneumohydraulic booster assembly
5320-1609510



Air-over-hydraulic booster
5320-1609510-30



Air-over-hydraulic booster
5320-1609510-40

Gearbox



2nd and 3rd gear synchronizer assembly
14.1701150



Mechanism control reducing valve assy
15.1772100



Gear splitter control valve with cable assembly
15.1772132



Lever
152.1703620-20



Ball joint
362-1703521-20



Gear Shift Linkage Rod Assembly for KAMAZ 152 Gearbox
362-1703620-20



Gear Shift Linkage Rod Assembly for KAMAZ 152 Gearbox
362-1703620-20СБ

Propeller shafts



Universal joint cross
4310-2205025



Spider assembly
53205-2205025

Front axle



Axle shaft
4310-2304062



Axle shaft
4310-2304064



Axle shaft
4310-2304065



Universal joint
4310-2304066



Disc
4310-2304067



Front wheel hub drive flange
4310-2304090



Axle shaft drive flange gasket
4310-2304091



Axle shaft
53228-2304064



Axle shaft
53228-2304065

Rear axle



Axle shaft
43118-2403069



Axle shaft
43118-2403070




Drive bevel gear
5320-2402017



Rear axle bevel gear set
5320-2402020



Rear axle drive shaft
5320-2402024



Bearing cup cover gasket
5320-2402047



Rear axle driven bevel gear
5320-2402060



Drive pinion
5320-2402110-10



Ring gear
5320-2402120-10



Driven spur gear
5320-2402120-20



Driven spur gear
5320-2402120-30



Driven spur gear
5320-2402120-40



Planet gear
5320-2403055



Cross pin
5320-2403060



Right short axle shaft
5320-2403070



Left long axle shaft
5320-2403071



Rear axle flange
53205-2402036



Drive spur gear
53205-2402110-10



Thrust washer
53205-2402175



Rear axle adjusting bushing
53205-2402188



Rear axle adjusting bushing
53205-2402189



Side gear
53205-2403050



Right axle shaft
53205-2403070



Left axle shaft
53205-2403071



Differential shell
53229-2403016




Axle shaft
53229-2403069



Axle shaft
53229-2403070



Left axle shaft
53229-2403071



Rear axle gearbox bearing cup cover
54115-2402051

Intermediate axle



Input shaft flange assembly
5320-2506037



Planet pinion washer
5320-2506058



Intermediate axle bevel gear
5320-2506130



Sleeve of interaxle differential middle axle drive gear
5320-2506131



Inter-axle differential planet pinion with bushing
53205-2506054



Inter-axle differential planet pinion without bushing
53205-2506055-10



Inter-axle differential spider
53205-2506060



Inter-axle differential planet pinion bushing
53205-2506063



Interaxle differential spider assembly with planet pinions without bushing (repair kit)
53205-2506081



Interaxle differential spider assembly (repair kit)
53205-2506081-20



Flange
6520-2502036

Fifth wheel coupling



Tow hook
5320-2707212

Suspension



Torque rod
1630-2919010-20



Balancer axle nut
5320-2918169



Balance shaft
5511-2918050



Balance shaft
65115-2918050



Balance shaft
65115Y-2918050



Balancer axle nut
6520-2918169

Wheels and tyres



Repair kit
4310-3103076



Repair kit
4310-3103079



Repair kit
4310-3103081



Repair kit
4310-3103082



Repair kit
5320-3104076



Repair kit
5320-3104079



Repair kit
5320-3104081



Repair kit
5320-3104082



Repair kit
53205-3104000



SZAP trailer hub
53222-3104015



Repair kit
6520-3104000

Steering



Power steering pump assembly
4310-3407200



Pump assembly
4310-3407200-01



Power steering pump
4310-3407200-01(-02)



Power steering pump
4310-3407200-02



Power steering pump
4310-3407200-20



Power steering pump
4310-3407200-21



Steering tie rod assembly
53205-3414010



Steering tie rod assembly
6520-3414010

Brakes



Pressure regulator assembly
100-3512010



Pressure regulator assembly
100-3512010-10



Brake valve assembly
100-3514008



Dual-circuit brake valve repair kit
100-3514009



Dual-circuit brake valve repair kit
100-3514009-10



Single-circuit protection valve without reverse flow
100-3515010



Triple protection valve assy
100-3515210



Relay valve assy
100-3518010



Relay valve
100-3518010-10



Isolating valve assembly
100-3520010



Isolating valve assembly
100-3520010-10



Parking brake valve with manual control
100-3537010



Brake drum
53205-3501070



Brake drum
6520-3501070

Instruments



Oil pressure gauge
14.3830010



Oil pressure gauge sender
5320-3829010