

COMMON



Differential case

375-2403022



Differential case

4320-2403014-01



Differential case

4320-2403022



Tie rod end body


4320-3414016

**Tie rod end body**

4320-3414062

**Tie rod end body**

4320-3414063

**Differential case**


4320BY-2403022-10

**Flange**

53205-2402036

**Steering tie rod assembly**

53205-3414010

**Brake drum**

53205-3501070

**Flange**

6520-2502036

**Steering tie rod assembly**

6520-3414010



Brake drum
6520-3501070

KAMAZ

Gasket
—



Clutch release fork
14.1601203



Torque rod
1630-2919010-20



Axle shaft
4310-2304062



Axle shaft
4310-2304064



Axle shaft
4310-2304065



Universal joint

4310-2304066



Disc

4310-2304067



Repair kit

4310-3103076



Repair kit

4310-3103079



Repair kit
4310-3103081



Repair kit
4310-3103082



Axle shaft
43118-2403069



Axle shaft
43118-2403070



Drive pinion
5320-2402110-10



Ring gear
5320-2402120-10



Differential pinion
5320-2403055



Cross pin
5320-2403060



Tow hook
5320-2707212



Balancer axle nut
5320-2918169



Repair kit
5320-3104076



Repair kit
5320-3104079



Repair kit
5320-3104081



Repair kit
5320-3104082



Side gear
53205-2403050



Repair kit
53205-3104000

**Axle shaft**

53228-2304064

**Axle shaft**

53228-2304065

**Differential shell**

53229-2403016

**Axle shaft**

53229-2403069



Axle shaft

53229-2403070



Balance shaft

5511-2918050



Balance shaft

65115-2918050



Balance shaft

65115Y-2918050



Balancer axle nut

6520-2918169



Repair kit

6520-3104000

URAL



Flange

375-1802079



Flange

375-1802264

**Driveshaft**

375-2202010-02C5

**Driveshaft**


375-2203010-05C5

**Sliding yoke**

375-2303072

**Universal joint**

375-2303074



Disc

375-2303075



Side gear

375-2403050-20



Differential pinion

375-2403057



Cross pin


375-2403060



Axle shaft
375-2403070-11



Nut
375-2918039



Nut
375-3103000



Repair kit
375-3103077



Repair kit
375-3103079



Repair kit
375-3103080



Repair kit
375-3103081



Driveshaft
43114-2202011-01



Driveshaft

4320-2201010-03



Driveshaft

4320-2203011-10



Wheel hub

4320-3103012



Brake drum

4320-3501070

**Driveshaft**

4320N-2203010

**Drive pinion**

4320X-2402110

**Ring gear**

4320X-2402120

**Leaf spring eye**

4320X-2902015



Brake drum
4320X-3501070



Driveshaft
4320E-2205010



Axle shaft
5557-2303065




Axle shaft
5557-2303070-10

**Axle shaft**

5557-2303071-10

**Sliding yoke**

5557-2303072

**Universal joint**

5557-2303074

**Disc**

5557-2303075

**Flange**

55571-1802211

**ABS tone ring**

55571-3533020

**Straight lever**

6330-2919060-02

**Driveshaft**

6361RX-2201010



Driveshaft
6361RX-2203010



Driveshaft
6361RX-2205010



Driveshaft
6361RX-2205012



Flange
6361RX-2402140

**Flange**

63619X-2502134

**Straight lever**

640-2919016